

Fine Tuning your Samsung Document Camera

Find your black remote that says Samsung in your black projector case. Put the batteries in if needed.

Using the remote will enable you to more efficiently make adjustments as you teach.

It is recommended that first thing every morning you “balance” your contrast on your Samsung.
To do this, using your remote, zoom in as far as you can on a white paper with text on it. Then select the AWC button. Then zoom out and it is ready.

To zoom in and out press the wide or tele buttons.



To adjust contrast press the bright + or Bright - buttons



The INT/EXT button that allows you to switch back and forth between the computer and the doc camera is on the top left corner under the power button.

You can power the lamp on and off (without unplugging it!) using the lamp button.



Focus manually by pressing the F (far) Or N (near) buttons.

Focus Automatically by pressing the AutoFocus button.

See the user's manual for other Features of the remote.

